




NOTE:  
FOR ALL COURSES,  
ALWAYS START CONSTRUCTION AT CORNERS  
AND WORK OUT INTO MIDDLE OF WALL





BRUTE CORNER UNIT

BASE COURSE




SECOND COURSE

MAINTAINING RUNNING-BOND  
IS NOT NECESSARY



THIRD COURSE



OUTSIDE 90° CORNER

INSIDE 90° CORNER

INSTALLATION SEQUENCE

SCALE: NONE

NOT FOR CONSTRUCTION

THESE PRELIMINARY DETAILS ARE INTENDED AS AN AID IN DESIGNING ATTRACTIVE, DURABLE RETAINING WALLS WITH VERSA-LOK STANDARD UNITS. FINAL DETERMINATION OF THE SUITABILITY OF ANY INFORMATION OR MATERIAL FOR THE USE CONTEMPLATED, AND ITS MANNER OF USE, IS THE SOLE RESPONSIBILITY OF THE USER. A FINAL PROJECT SPECIFIC DESIGN SHOULD BE PREPARED BY A QUALIFIED, LICENSED, PROFESSIONAL ENGINEER.



**VERSA-LOK®**  
Retaining Wall Systems

(800)770-4525 fax(651)770-4089  
6348 Hwy36 Ste1, Oakdale,MN 55128 **Solid Solutions™**

BRUTE DETAILS

CORNER DETAILS

SCALE: AS NOTED

DRAWN BY: PPS

CHECKED BY:

DATE: 10/04

DWG. NO. brute corner details